



**CRUISE  
MATE**  
MOTORCYCLE  
CRUISE ASSIST

Product of  
**IRON  
BRAID**

Po Box 300  
East Nassau NY 12062  
518.674.0100  
web: [www.ironbraid.com](http://www.ironbraid.com)  
email: [info@ironbraid.com](mailto:info@ironbraid.com)

## CRUISE-MATE INSTALLATION INSTRUCTIONS

Before adjusting the CruiseMate, make sure the throttle moves freely with the CruiseMate in the OFF position (handle fully resting against the rear cable/stop pin). If the throttle doesn't return smoothly, check that the CruiseMate isn't holding it open. In about 95% of cases, poor throttle return is due to dry or poorly lubricated cables. Apply cable lubricant thoroughly and let it work through the entire cable length. Test the throttle again to ensure it returns properly.

### CRUISE-MATE HAS 2 POSITIONS "OFF" & "ON"

**"OFF" POSITION** – Handle is resting back against the cable/stop pin.

Ensure the throttle moves freely and snaps back to the closed position when released. If it doesn't return fully, refer to "CruiseMate is Too Tight".

**"ON" POSITION** – Handle is pushed forward, away from the cable/stop pin.

With the engine off, open the throttle about halfway. Push the CruiseMate handle forward about ¼ turn, then release the throttle. If the throttle doesn't hold its position, see "CruiseMate is Too Loose"..

### CRUISE-MATE IS TOO TIGHT

"Throttle doesn't move freely when the Cruise-Mate Handle is in "OFF" Position"

- 1.) Pull the CruiseMate handle back toward the rear of the bike so it rests against the cable/stop pin.
- 2.) Pull down on the handle and rotate it one tooth forward (toward the front of the bike), then re-engage the handle splines with the insert splines.
- 3.) Return the CruiseMate handle to the OFF position.
- 4.) Repeat steps 1–3 until the CruiseMate fully releases the throttle in the OFF position

### CRUISE-MATE IS TOO LOOSE

"Throttle doesn't stay open when Cruise-Mate Handle is in the "ON" Position"

- 1.) With the bike OFF, open the throttle and push the CruiseMate handle forward (toward the front of the bike) until it begins to hold the throttle open.
- 2.) Pull down on the handle, rotate it one tooth toward the rear of the bike, and re-engage the handle splines into the insert splines.
- 3.) Return the handle to the OFF position.
- 4.) Repeat steps 1–3 until the CruiseMate securely holds the throttle in place when in the ON position.

#### Disclaimer:

The Cruise-Mate is designed for motorcycle warm-up and maintenance purposes only. Never remove your hands from the handlebars while the motorcycle is in motion.

You can find links on our website to Cruise-Mate installation, adjustment instructions, and instructional videos.



A Product of IronBraid  
763 Central Nassau Rd  
East Nassau NY, 12062  
518.674.0100



web: [www.ironbraid.com](http://www.ironbraid.com)

web: [www.ironbraid.com](http://www.ironbraid.com)—email: [info@ironbraid.com](mailto:info@ironbraid.com)